

# Bottle Filler, Cooler, and Fountain Cross Reference Guide

## Haws to Elkay



Haws	Elkay Direct Cross	Elkay Alternative
<b>Bottle Filling Stations</b>		
1900	EZWSRK	
1900	EZWSSM	
2000S	LZWSMDPK	
2000S w/ Chiller	LZWSM8K	
2000SMS	LZWSM	
2000SMS w/ Chiller	LZWSM w/ Chiller	
<b>Water Coolers</b>		
H1001.8	ERPBMV8K	
H1011.8	ERPBMV28K	
H1011.8HO	ERPBMV8K	
H1011.8HPS	ERPBMV28K	
H1109.8	ERFPVRM8K	
H1119.8	ERFPVR28K	
HWBFA8.VRC	VRCHD8S	
HWBFA8L.VRC	VRCHDTL8SC	
HWUACP8	EZS8L	EMABF8L
HWUACP8 w/6426	LZS8L	LMABF8L
HWUACP8L	EZSTL8LC	EMABFTL8LC
HWUACP8L w/6426	LZSTL8LC	LMABFTL8LC
HWUACP8LSS	EZSTL8SC	EMABFTL8SC
HWUACP8SS w/6426	LZS8S	LMABF8S
HWUACP8LSS w/6426	LZSTL8SC	LMABFTL8SC
HWUACP8SS	EZS8S	EMABF8S
HCF05	FD7005L	
HFO8	EFA8L	
HFO8 w/6426	LFAE8S	
HWCT8	EHFRAM7K*	
HWO8	EWA8L	
HWO8 w/6426	LWAE8L	
<b>Drinking Fountains</b>		
1001	EDFPBV114C	
1075	EDFPVR214RC	
1085	EDFPVR217RC	
1105	EDFP210FPK	
1109	EDFPVR214C	
1109.14	EHW214C	
1119	EDFPVR217C	

Haws	Elkay Direct Cross	Elkay Alternative
1119.14	EHW217C	
1152	EDF15R	
1408	EDFPVR320RC	
4010	DRKR10C	DRKR14C
1001BP	EDFPBMV114C	
1001HPS	EDFPBV114C	
1001MS	EDFPBMV114K	
1011HPSMS	EDFPBMV117C	
1011MS	EDFPBMV117C	
1107L	EHW214C	
1107LBP	EHW217C	
1109FR	EDFP214FPK	
1117L	EHW217C	
1117N	EHW217C	
1119FR	EDFP217FPK	
1011	EDFPBM117K	
1311	EDFPVR214RC	
1409	EDFPVR320RC	
1430	EDFPVR220RC	
1431	EDFPVR220RC	
1435	EDFPVR320RC	
1441	EDFPVR220RC	
1501	EDFPVR217RC	
2405	EDFB12C*	
2406	EDFBC212C*	
1011HPS	EDFPBM117K	
1105BP	EDFP210FPK w/ WP2	
1109BP	EDFPVR214C w/ WP2	
1109FRBP	EDFP214FPK w/ WP2	
<b>Chillers</b>		
HCR8	ECH8	

\*Add Vandal Resistant Bubbler for a direct cross.

### Haws Model Number Key

FR	Freeze Resistant
BP	Back Panel
.14	14 gauge
.8	Refrigerated
HPS	High Polish
MS	Mounting System
HO	Sensor
L	Low Profile Basin
N	Narrow Profile Basin